


REVOTOOL®

K90GN50B



Pos. Nr.	Artikel Nr.	Beschreibung
101	T90GB-101	Luftabweisedeckel
102	T90GB-102	Schrauben
103	T90GB-103	Deckel
104	T90GB-104	Puffer
105	T90GB-105	Feder
106	T90GB-106	O-Ring
107	T90GB-107	Ventilschieber
108	T90GB-108	O-Ring
109	T90GB-109	O-Ring
110	T90GB-110	Flachdichtung
111	T90GB-111	Ring
112	T90GB-112	O-Ring
113	T90GB-113	O-Ring
114	T90GB-114	Kolben kompl.
115	T90GB-115	O-Ring
116	T90GB-116	Zylinder
117	T90GB-117	Zylinder Ring
118	T90GB-118	Puffer
119	T90GB-119	Führung
201	T90GB-201	Dichtung
202	T90GB-202	Ventil-Oberteil
203	T90GB-203	Feder
204	T90GB-204	Ventilstange
205	T90GB-205	O-Ring
205A	T90GB-205A	O-Ring
206	T90GB-206	O-Ring
207	T90GB-207	Ventil-Führung
208	T90GB-208	Stift
209	T90GB-209	Stift
210	T90GB-210	Abzug
211	T90GB-211	Sicherung
212	T90GB-212	Ring
301	T90GB-301	Gehäuse
302	T90GB-302	Ring
303	T90GB-303	Deckel Hinten
304	T90GB-304	Nippel
305	T90GB-305	Staubschutz
401	T90GB-401	Schrauben
402	T90GB-402	Klappe

Pos. Nr.	Artikel Nr.	Beschreibung
403	T90GB-403	Führung
404	T90GB-404	Stift
405	T90GB-405	Feder
406	T90GB-406	Schraube
407	T90GB-407	Werkzeugplatte
408	T90GB-408	Magazin Unterteil
409	T90GB-409	Blech
410	T90GB-410	Schrauben
411	T90GB-411	Anschlag
412	T90GB-412	Magazin Oberteil
413	T90GB-413	Magazinschieber
414	T90GB-414	Stange
415	T90GB-415	Magazinfeder
416	T90GB-416	Platte hinten
417	T90GB-417	Abdeckung
418	T90GB-418	Unterlagscheibe
419	T90GB-419	Schraube
420	T90GB-420	Halterung
421	T90GB-421	Drehfeder
422	T90GB-422	Stift
423	T90GB-423	Hebel
424	T90GB-424	Rastscheibe
425	T90GB-425	Unterlagscheibe
426	T90GB-426	Hebel
427	T90GB-427	Stift
428	T90GB-428	Feder
429	T90GB-429	Schrauben
430	T90GB-430	Stift
431	T90GB-431	Führung
432	T90GB-432	Stopper
433	T90GB-433	Feder
434	T90GB-434	Ring
435	T90GB-435	Sicherung
436	T90GB-436	Justierring
437	T90GB-437	Sicherungstaster
438	T90GB-438	Schraube
439	T90GB-439	Schraube
440	T90GB-440	Block
441	T90GB-441	Mutter